


FURNITURE RAISERS



QDL730-A - large raisers

QDL730-B - small raisers

QDL730-C - adapter raisers



LSR530

Rubber tips - **TSA530-A**
Backrest (specify colour) - **TSA530-B**
Seat (specify colour) - **TSA530-C**
Arm Rest (specify colour) - **TSA530-D**
Lever and Cables - Recline - **TSA530-E**
Footrest lever and cable - **TSA530-F**
Height Adjustable Extension Legs - **TSA530-G**
Gas Strut - Legrest - **TSA530-H**
Gas Strut - Backrest - **TSA530-I**
Optional Table Top - **TSA530-J**

LSR531

Rubber tips - **TSA530-A**
Backrest (specify colour) - **TSA531-B**
Seat Cover (specify colour) - **TSA531-C**
Arm Rest (specify colour) - **TSA531-D**
Lever and Cables - Recline - **TSA530-E**
Footrest lever and cable - **TSA530-F**
Height Adjustable Extension Legs - **TSA530-G**
Gas Strut - Legrest - **TSA530-H**
Gas Strut - Backrest - **TSA530-I**
Optional Table Top - **TSA530-J**

LSR532

Rubber tips - **TSA530-A**
Backrest (specify colour) - **TSA532-B**
Seat (specify colour) - **TSA532-C**
Arm Rest (specify colour) - **TSA530-D**
Height Adjustable Extension Legs - **TSA530-G**

LSR533

Rubber tips - **TSA530-A**
Backrest (specify colour) - **TSA533-B**
Seat (specify colour) - **TSA533-C**
Arm Rest (specify colour) - **TSA531-D**
Height Adjustable Extension Legs - **TSA530-G**

LSR535

Rubber tips - **TSA370-A**
Backrest (specify colour) - **TSA535-B**
Seat (specify colour) - **TSA535-C**
Arm Rest (specify colour) - **TSA535-D**

LSR540 / 541

Castor - **TSA540-A**
Hand Controller - **TSA540-B**
Motor - Lift Mechanism - **TSA540-C**
Motor - Backrest - **TSA540-D**
Battery Backup Unit - **TSA540-E**

LSR542 / 543

Castor - **TSA540-A**
Hand Controller - **TSA542-B**
Motor - **TSA542-C**
Battery Backup Unit - **TSA540-E**

LSR555

Castor - **TSA555-A**
Hand Controller - **TSA555-B**
Motor - **TSA555-C**
Battery Backup Unit - **TSA555-E**
Seat Cover - **TSA555-F**
Backrest Cover - **TSA555-G**
Armrest Cover - **TSA555-H**
Side Wing Cover - **TSA555-I**